



# E-Z LIFT TOGGLES TO RAISE TOP IN MORGAN 4-SEAT

NOTE: LOCATE CARRIAGE BOLT HOLE SO THAT HANDLE-END OF LEVER ARM WILL HAVE  $\frac{1}{2}$ " CLEARANCE ABOVE VEHICLE WHEN UP IS ERECTED

- 1) DRILL HOLE IN VEHICLE'S SUPPORT FOR BOWS
- 2) DRILL  $\frac{1}{4}$ " HOLE
- 3) DRILL FOR CARRIAGE BOLT:  $\frac{1}{4} \times 1$ ", GRIND OFF HEAD TO  $\frac{1}{16}$ " THICK

